



NOTES:

- TRACER WIRE MUST LAY FLAT AND STRAIGHT. NO COILS MAY BE PRESENT
- ALL CONNECTIONS MUST BE SOLDERED AND WATERTIGHT
- TAPE MUST NOT BE DAMAGED OR TORN
- TRACER WIRE RUN MUST NOT EXCEED 300' WITHOUT ADDITIONAL TEST STATION

LINK SEAL SHALL BE PROVIDED AT WALL PENETRATIONS AS APPLICABLE

DRAWN BY: TS
 CHECKED BY:
 SCALE: N.T.S.
 DATE: 04/25/2022

STORM / SANITARY SEWER COMPACTION
 & TRACER WIRE INSTALLATION

RUTGERS
 THE STATE UNIVERSITY
 OF NEW JERSEY
 UNIVERSITY FACILITIES PISCATAWAY,
 NEW JERSEY

SK-44